PART OF AUTO-AUTO RELAY SET TEST UNIT GBW 11541 OR EQUIV.
EXPLANATORY ONLY.

DUPLICATE DISPLAY PANEL

FIG. 1B.

PART OF AUTO-AUTO RELAY SET TEST UNIT GBW 12520 OR EQUIV.
EXPLANATORY ONLY

DUPLICATE DISPLAY PANEL

FIG. 1C.

PART OF UNISELECTOR ACCESS CONTROL UNIT GBW 11490 OR EQUIV.
EXPLANATORY ONLY

DUPLICATE DISPLAY, PART OF FIG. 1A

PART OF UNISELECTOR ACCESS CONTROL UNIT GBW 11490 OR EQUIV.
EXPLANATORY ONLY

DUPLICATE DISPLAY PART OF FIG. 1A

NOTES

1. FUSING, RESISTORS AND ALARM LAMPS FUSED WITH ASSOCIATED TEST AND ACCESS CONTROL UNITS. BATTERY JACKS FUSED WITH BATTERY JACKS ON ASSOCIATED UNITS.
2. WIRING SHOWN — | — | — MUST BE DISCONNECTED & WIRING SHOWN — x — x — MUST BE ADDED ON THE ASSOCIATED TEST & ACCESS CONTROL UNITS WHEN THIS DUPLICATE DISPLAY PANEL IS PROVIDED.
3. THE LINK MUST BE REMOVED FROM TJ 9 & 10 ON THE ASSOCIATED TEST UNIT WHEN THIS DUPLICATE DISPLAY PANEL IS PROVIDED.
4. THE LEADS CABLED FROM THE DISPLAY PANEL ARE TO BE TERMINATED ON THE TEST UNIT AND ACCESS CONTROL UNIT ACTUALLY AS SHOWN.
5. USE FIGURES 1A1B TO PROVIDE DUPLICATE DISPLAY FOR AUTO-AUTO RELAY SET TEST UNIT GBW 11541 OR EQUIV. USE FIGURES 1A&1C TO PROVIDE DUPLICATE DISPLAY FOR ROUTINER TO GBW 12520 OR EQUIV.
6. ALL WIRING TO BE 25 SWG. UNLESS OTHERWISE SPECIFIED.

-VE FAULT IMITATION (KNF)	+VE FAULT IMITATION (KPF)	BUSY FAULT IMITATION EARTH (KBF)	TRANSMISSION TEST (KTT)
5	5	2	2

ALM. EXT. (KAE)	PRIM STEP (KPS)	SEC. STEP (KSS)	ACC. STEP (KSA)	RESET (KR)	STEP ON (KSO)	START (KS)	MAIN ALM. (KMA)	CONT. RTE (KCR)	ALM. TEST S (KAS)	ALM. TEST Z (KAZ)
4	2	2	5	2	4	8	2	6	5	6