



NOTES

- FUSING:-
 FIG. 1, AP 1-5A AD 1-5A
 FIG. 1A AP 1-5A AD 1-5A
 FIG. 2 AND 4 P AND AP 1-5A
 D AND AD 1-5A
 FIG. 5 & 5A PER FLOOR (MAXIMUM 4 LAMPS PER FUSE) 3-0A
 FIG. 6 PER FLOOR (MAXIMUM 4 LAMPS PER FUSE) 3-0A
 FIG. 7 PER SECTION (MAXIMUM 4 LAMPS PER FUSE) 3-0A
 FIG. 8 PER FLOOR 1-5A
 FIG. 9 PER FLOOR 1-5A
 FIG. 14 PER EXCHANGE 1-5A
 FIG. 15A OR 15B PER FLOOR 1-5A
 FIG. 16A OR 16B PER EXCHANGE 1-5A
 FIG. 16C OR 16D PER EXCHANGE 1-5A
 WHEN GROUP FUSES ARE PROVIDED THE ABOVE FUSES ARE FITTED ON THE AUXILIARY GROUP FUSE PANEL, OTHERWISE ON THE A.E.R.
 FIG. 12C PER KEY 1-5A
 FIG. 13 RELAY OR 1-5A
 LAMP AND BUZZER 1-5A
- THE DIAGRAM SHOWS THE MAXIMUM NUMBER OF TAGS PER FLOOR ON THE ALARM STRIP CONN. AND BATT. STRIP CONN. EACH FLOOR MAY CONTAIN UP TO 4 SECTIONS INCLUDING THE POWER AND CARRIER SECTIONS.
- WHEN SECTION BELLS ARE NOT PROVIDED STRAP TAGS 56, 57 AND 60 IN FIG. 8, TO ENABLE THE FLOOR BELL TO ACT AS A SECTION BELL WHEN THE FLOOR BELL CUT-OFF KEY IS THROWN.
- WHEN FLOOR BELLS ARE PROVIDED ON SINGLE FLOOR EXCHANGES, STRAP TAG 54, FIG. 9 TO TAG 55, FIG. 10 TO COMPLETE THE FLOOR BELL CIRCUIT.
- BUZZER AND LAMP MOUNTED WHERE REQUIRED
- WHEN ENGINEERING STAFF ARE IN CONTINUOUS ATTENDANCE OMIT WIRING TO RELAY 'AE' AND ADD STRAPS
- THESE TERMINALS ON BATT. STRIP CONN PROVIDED ONLY WHEN FUSES ARE ON AUXILIARY GROUP FUSE PANEL.

