FIG4
NOTE 8.
FIG1
SECONDARY DISTRIBUTOR
FIG2
RESET JACK EXPLANATORY ONLY
FIG3
NOTES.
TO NEXT RACK
FROM TEST UNIT OR PREVIOUS RACK
TO AUTO-AUTO RELAY SETS OR EQUIV.
NOT TO BE USED FOR NEW WORK.
ROUTINE ACCESS SELECTOR UNISELECTOR WITH SECONDARY DISTRIBUTION FOR AUTO TO AUTO RELAY SETS WITH OR WITHOUT REPEATWETER
GBW 15900