


MANUAL BOARD OR DIRECTORY SERVICE DESK
EXPLANATORY ONLY




- NOTES**
1. FUSE 1.5 AMP PER RELAY SET 2 CIRCUITS.
 2. SHELF JACK POINT U9-U11 AND U17-U19 TO MAKE CONTACT WHEN THE RELAY SET IS REMOVED.
 3. Ø FOR WIRING SEE GBW 10640 OR EQUIVALENT.

NZ NOTE
WHEN USED IN CONJUNCTION WITH N.Z 34738
PROVIDE STRAP -1- AND CONN -2-


BATT. W U12-1RB1b-2RB1b-2Be-255e-155e-1Be-1R1b-2R1b
ETH. R. U11-1L2-11b-11e-15d-151-25d-251-21b-21e-2L2
2B3-2551-2554-1551-1554-1B3-1RB1d-1TJ1-2TJ1

BATT BK 0.95WG FUSE (3B) U12
ETH R 0.95WG ETH BAR (3A) U11-U17



TO DIR. SERV. DESK
GBW 12940
FIG. 6
OR 34738
(NZ NOTE)
WHAN REQD

LAMP RELAY
VIA SWITCHING EQUIPT.
(GBW 12710 FIG. 2)
WHEN REQUIRED.




RETRACED	(17006)	4B	12-12-79
NZ NOTE ADDED F.U. HAMILTON	(89132)	4A	30-7-68 G.E.
REF TO I.D.F. LOCAL ADD. TO 1/C LEADS	(67435)	4	10-7-56 C.W.H.
1/C CONNS TO I.D.F. ADDED		3	
DESTINATION OF 'L' LEAD AMENDED		2	
		1	

AMENDMENT PARTICULARS				ISS	DATA	APP	GS3 21-21	SIZE A3	50V	S
TJ	NZPO			DRAWN	CHECKED	WIRING	CIRCUIT			
8				N.S.						

SELECTOR LEVEL RELAY SET
(SLEEVE CONTROL MANUAL BOARD)
2000 TYPE

GBW 12570
MOD A



PROOF