



- NOTES**
1. FUSING - ALL FUSES ON ALARM EQUIP. FUSE PANEL ON R.E.R. UNLESS OTHERWISE STATED.
 2. FIG. 1A, AP1-AP3, AD1-AD3, AP2-AP3, AD2-AD3, AP3-AP3, AD3-AD3, AP3-AP3, AD3-AD3.
 3. FIG. 3 - 3 LAMPS PER SECTION (3 LAMPS MAX).
 4. FIG. 5A FUSED WITH FIG. 15A - 1.5A.
 5. FIG. 5B FUSED WITH FIGS. 11 & 12 - 1.5A (FUSED ON MAIN B.D.).
 6. FIG. 7A - 1.5A PER OUTLYING EXCH.
 7. FIG. 7B - 1.5A PER OUTLYING EXCH.
 8. FIG. 7C - 1.5A PER OUTLYING EXCH.
 9. FIG. 8A FUSED WITH FIGS. 8A & 9A - 1.5A (FUSED ON TEST DESK, TEST RACK OR A.E.R.).
 10. FIG. 10 AND 11 - 1.5A PER FIG.
 11. FIG. 16 - 3.0A PER FLOOR (3 LAMPS MAX).
 12. FIG. 17A - 3.0A PER FLOOR (3 LAMPS MAX).
 13. FIG. 17B - 3.0A PER FLOOR (3 LAMPS MAX).
 14. THESE TERMS ARE NOT REQUIRED WHEN FIGS. 8A, 8B, 8C & 9A ARE EQUIPPED ON A.E.R.
 15. THESE TERMS ONLY REQUIRED WHEN FIG. 9A IS EQUIPPED ON A.E.R.
 16. WHEN FIGS. 8A & 8B ARE ON A.E.R. STRAP TERMS 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13 & 14 BATTERY AND ETH LEADS FROM THE FIRST WIRING POINT TO BE 25 SWG TO THE END OF THE RUN.
 17. THIS LEAD IS NOT REQ'D WHEN FIGS. 8A & 8B ARE ON A.E.R.
 18. KNT IS MECHANICALLY COUPLED WITH KNS ON GW 16100 OR EQUIV.
 19. WHEN FIG. 13B IS EQUIPPED ON A.E.R. STRAP TERMS 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13 & 14 BATTERY AND ETH LEADS FROM THE FIRST WIRING POINT TO BE 25 SWG TO THE END OF THE RUN.
 20. SPRING NUMBERS ENCLOSED IN BRACKETS APPLY TO THE RELAY FIG. 13B.
 21. Ø FOR WIRING SEE GW 1060 OR EQUIV.

FIG. NO.	DATE	AMENDMENT	PARTICULARS
1	10/1/58	1	ISSUE DATE
2	10/1/58	2	ISSUE DATE
3	10/1/58	3	ISSUE DATE

GBW 16220