

RELAY DESIGN FOR CIRCUIT **GBW 14141**

TITLE **PULSE CIRCUIT**
50/1200 LINE P.A.B.X.

COMMITTEE'S WIRING DIAGRAM NO. _____

RELAY NAME	COMM CODE	DEPARTURES FROM DIAGRAM		SPRING NUMBERING CONTACT UNIT NUMBER								REFERENCES TO NOTES BELOW			
		RESISTANCE	CONTACTS	1	2	3	4	5	6	7	8				
W PA ()	60374P				1 2 3 3	21 22 23 23									
W PB ()	60374P				1 2 3 3	21 22 23 23									
W BT B	6010				1 2 3 3	21 22 23 23									
W RA B	6010				C C	21 22 23 3	1 2								
W RB B	6010				C C	21 22 23 3	1 2								
W LH B	1529				1 2 M										

NOTES SPECIAL FACTORS OF SAFETY A
SPECIAL ADJUSTMENTS B
CIRCUIT POINTS OF MODIFICATIONS C

CLASS	RELAY	NOTES													
		<p> R1 = P.O. N°9 150 OHMS. R2 = P.O. N°6 200 " C1 = M.C. 0.1 MF RXI-4 = P.O. N°2 NON-LINEAR SELECTOR = 2/87A ON 2/80 BANK </p> <p style="text-align: right;">LAYOUT (FRONT VIEW)</p> <table border="1" style="margin-left: auto;"> <tr><td>RA</td><td>RB</td></tr> <tr><td>PA</td><td>PB</td></tr> <tr><td>LH</td><td>BT</td></tr> <tr><td colspan="2" style="text-align: center;">PS</td></tr> </table> <div style="text-align: center; margin-top: 10px;"> <p>CONDENSER BOX</p> <table border="1" style="display: inline-table;"> <tr><td style="width: 40px; height: 20px;"></td><td style="width: 10px; height: 20px;"></td><td style="width: 10px; height: 20px;">C1</td><td style="width: 10px; height: 20px;">R2</td><td style="width: 10px; height: 20px;">SPACER</td></tr> </table> <p>HINGE</p> </div>	RA	RB	PA	PB	LH	BT	PS				C1	R2	SPACER
RA	RB														
PA	PB														
LH	BT														
PS															
		C1	R2	SPACER											

APR
ISSUE: 1-1-58

DATE	1/1/58
SIGNED FOR COMMITTEE	R.E.D. S.T. & C.