



- NOTES -**
- 1 FUSING - 1.5A PER CIRCUIT
 - 2 JACK POINTS U9 & I1 AND U17 & I9 MAKE CONTACT WHEN RELAY SET IS REMOVED
 - 3 FOR WIRING SEE GBW 13300 OR EQUIVALENT
 - 4 ALL WIRING BEARING A COLOUR CODE TO BE 0.6mm UNLESS OTHERWISE SPECIFIED BANK & SELECTOR WIRING TO BE 0.5mm
 - 5 NPA SPRINGS MAKE ON NZ LEVELS 8 7 6 5 & 0 } 35 LINE
NPB 9 4 3 2 1 & 0 }
NPA 8 7 6 5 4 & 0 } 49 LINE
NPB 9 3 2 1 & 0 }
6 FOR SEQUENCE OF MULTIPLES & WIRING OF OUTLETS SEE EXTENSION LINE CIRCUIT GBW 13210 OR EQUIVALENT
 - 7 LEVEL & CONTACT NUMBERS SHOWN ARE IN ACCORDANCE WITH REVERSE NUMBERED N.Z. DIAL B.P.O. NUMBERING CORRESPONDING TO N.Z. NUMBERS 0 1 2 3 4 5 6 7 8 9 15 0 9 8 7 6 5 4 3 2 1 RESPECTIVELY
 - 8 MISCELLANEOUS CONNECTIONS FROM BANKS -

19 H	AS EXCHANGE LINE START	FROM MISC CCT
29 H	B5 NIGHT SERVICE START	GBW 14720 OR EQUIV
19 G	FROM LF 1/W FIG 1B	
29 G	NIGHT SERVICE BUSY EARTH	
06 H	OL H	FROM MISC CCT
06 +	OL +	GBW 14720
08 -	OL -	OR EQUIVALENT
09 H	OL W FROM ATT 5 LINE CCT	

- NZ PO NOTES**
- A WHEN ACCESS TO V.H.F. SERVICE VIA AN EXTENSION LINE CCT IS REQUIRED MODIFY CONNECTING CTS FOR CALLING PARTY RELEASE BY REMOVING WIRING SHOWN --- & INSERTING RECT MRI & WIRING SHOWN ---
- B ON SOME 35 LINE SYSTEMS THE HF MULT WIRING IS BROWN INSTEAD OF WHITE
- BATTERY BK FUSE** U12 LFe
- EARTH R ETH BAR** U11 R1a LF1J LF 2/50
- EARTH R ETH BAR** 18TG BANK OUTLET 09 MULT TO ALL BANKS
- BATTERY W** U12 He De R3b R4b R5b Aa Ee BTe VMe RMe R7b R9b
- EARTH R** U11 H25 H1 FT4 Da-Ae A1 B23 Ba K28 Ka K8 E5 E8-NR1-N5 R6a-R2a

FOR SEQUENCE OF MULTIPLES & WIRING OF OUTLETS SEE EXTENSION & NOTE B

SUPERSEDES GBW 13190

RETRACTED FROM 155 38 OF 19 10 73(157617)	SC	19 9 78 4 18
SUPERSESSION NOTE ADDED	5	
AMENDMENT PARTICULARS	155	DATE APP

SIZE A1 50V W

35/49 LINE PABX CONNECTING CIRCUIT

GBW 14660

N	NR	NPA	NPB	TJ	NZPO	DRAWN	CHECKED	WIRING	CIRCUIT
5	4	1	1	14		A.S.L.	R.F.H.	R.F.H.	RED